



The ReGENCY™ is a new breed of overdrive designed for high gain amps that acts like a pre-emphasis for the amplifier - accentuating the natural distortion with a greater degree of punch, harmonic generation and sustain. It features two sections: the first section is a Pre-Drive that features variable gain, drive and tone controls along with a 3-position low mid-switch. The second section is a super-high output power Booster. Each section is activated with a dedicated footswitch and may be operated separately or in tandem via true-bypass relay-based switching. A built-in effects loop enables a pedal like a delay to be activated at the same time as the power booster to instantly transition from rhythm to lead. Compact to fit in a pedalboard, the ReGENCY employs standard 9V for powering making it easy to integrate with most guitar setups.

Regency - Order # R800 7013 00

Features

- Pre-Drive to emphasize amplifier distortion
- Ultra-high gain power booster with +18dB of gain
- 3-position low mid switch to focus bottom end
- Built-in effects loop to add delay for soloing

Benefits

- Excites and spices-up the sound of your amplifier
- Adds sustain and harmonics for soloing
- Instantly activate effects with Booster
- Relay based switching for true-bypass performance

Cool Stuff

- Compact design is easy to integrate into pedalboard
- 9V operation for use with multi-pedal power bricks
- Adds tremendous versatility to your tonal options

9VDC - Connection for standard 9 volt DC power adapter (center pin negative).

OUT - 1/4" output for connection to your amp.

EFX LOOP - Send & return 1/4" jacks used to connect effects pedals. The EFX Loop is activated by using the Boost footswitch and used to add effects when soloing.

IN - Standard 1/4" input for your guitar.

BOOST GAIN - Variable Class-A power booster - 100% discrete with up to +23dB of clean gain.

LEVEL - Used to set the output volume level for the overdrive.

LOW-MID - 3-position switch used to tailor the bottom end of the circuit to adapt the tone to your guitar and amp setup.

DRIVE - Used to adjust the overall amount of distortion introduced in the overdrive circuit.

TONE - Brightens or darkens the overdrive circuit to suit your guitar and amp setup.

DRIVE FOOTSWITCH - Used to activate the overdrive circuit.

BOOST FOOTSWITCH - Activates the power booster and the effects loop.

LED INDICATORS - Ultra-bright LEDs let you know when the overdrive and power booster are active.

The Texas in your pedal chain

The ReGENCY lets you pre-emphasize the front end of your amp to add sustain and harmonics by adding slight overdrive and extra punch to your signal, without muddying up the notes.

Add other effects pedals when using the Boost

The Boost footswitch automatically engages the effects loop, bringing chorus or delay into the signal path along with the Power Booster. This lets you switch from rhythm to lead with a single foot-stomp, making your transitions easier and adding excitement to the performance.

